




x





































































































































LEGO.com/service or dial



00800 5346 5555:

1-800-422-5346:













4271949

4211150

4517986

6171066

6254045

2x

1x

1x

6335169

4177932









306924



2x 6310247























403223



6309005



































6126082

2x 6132886

2x 4494475

2x

2x

4x

4x

4211393

6294703

6171894

4654577





4211795

6308987

6317954

10x

2x 6115080








**6x** 4211000







6099909









1x 4211085



4211088





1x



4211002

